
PAIRING MYPACE REMOTE TO BUDDY SMART REEL®


The MyPace handheld remote should be delivered already paired to the Buddy Hose Reel. If several reels have been purchased and it is not clear as to which remote is paired to which reel or if the remote has been replaced, the remote can be re-paired to the reel at any time.

How to pair the MyPace remote

1. Stand within reach of the Buddy Reel switch panel.



- **2.** Ensure the reel is powered and switched on. (\square will appear in the "Codes" section)
- **3.** Remove the batteries from the remote.
- **4.** Press both buttons on the remote and insert the batteries while holding the buttons.



- **5.** Green lights will flash slowly on the remote and the display on the switch panel on the reel will slowly flash PA.
- **6.** Within 10 seconds, press the manual rewind button on the reel switch panel.
- 7. Successful pairing will be acknowledged by the display on switch panel flashing PA fast for a few seconds then return to a steady \Box . (The green light on the remote may continue to flash slowly for a few seconds then stop).
- **8.** After the green light on the remote stops flashing, press either button to confirm that the reel is responding.

Singleton NSW 2330 1800 011 000