

SPRAYSCOUT TANK

BASIC TROUBLESHOOTING GUIDE

EMPTYING THE TANK

Do you have the black pipe that was included in the unit's bag of items?

YES

Find in the bottom of the tank a black filter with a yellow cap.

Remove the yellow cap then push the black pipe in it's place.

Once you push it all the waym, it will open the shut off valve and the liquid will come out.

NO

Remove the yellow cap in the suction filter at the bottom of the tank.

Use an item that can help push the pin to open the shut off valve.

Once the shut valve is open water will start flowing out.

Note: We can have one of the pipes sent out to customer.

END

Rapid Spray